

BISSUE: 0222

FIXING PACK CODE: MSFP2


Making British gardens great

Thank you for purchasing your shed from Forest Garden. No matter what size garden, a shed is the most practical of garden structures. Simply follow these step by step instructions and our top tips and you'll be enjoying your shed for many years to come. If you have any questions or need advice, our friendly team is here to help.

SHED INSTRUCTIONS

PENT SHEDS (6x4, 7x5, 8x6, 10x6)

FIXING PACK CONTAINS:




Missing something or need more information? Call our aftersales team on 0333 321 3142 Visit our website for spare instructions and more information www.forestgarden.co.uk

Please read through these instructions to familiarise yourself with your shed. We recommend that you **check all the components** using the lists found on the front and back pages before you start to build.

All of our sheds are constructed in the same way. They simply come with different components depending on the type of shed you have. Don't worry if your fixing pack contains some spare items at the end of the build (you haven't missed a bit!) we have sent you a generic fixing pack to suit the shed range.

BASE PREPARATION

It's vital that you build your new shed on a **solid**, **level base**. Timber or Plastic Shed Bases are ideal, as is solid concrete or concrete slabs.




Timber BaseSelf-constructed/
Buy pre-made



Concrete
Concrete surface/
Concrete slabs



Pro Shed Base Interlocking eco-friendly base



Broken Slabs/Gaps
Uneven slab sizes
with no cement



Soil A base of soil only

If you have an existing base and think it's suitable for your new shed to be sited on, it is important you check that it is level and doesn't deviate by any more than 15mm from edge to edge. If this isn't the case the building will twist, causing gaps to appear in the sections and the roof, doors and windows to misalign.

There's more information on base preparation on our website www.forestgarden.co.uk

TOOLS NEEDED

We recommend using the following tools (not supplied):



Tape Measure



Sharp Knife



Screwdriver



Drill & 2mm Drill Bit



Hammer



Ladder



Spirit Level

Assembly is relatively straightforward if your follow these step by step instructions. We recommend getting everything aligned properly before screwing together and that screw holes should be pre-drilled to avoid splitting the timber.





To help you get the most out of our products it's useful to know a little more about the properties of timber, what's normal and how your shed may behave as the seasons change. Wood is an extremely durable material for construction but as a natural product when used outdoors it is susceptible to changes in the environment.

THINGS THAT YOU MIGHT SEE IN YOUR PRODUCT



MOVEMENT, TWISTING & WARPING

Wood contains a natural level of moisture so decreasing humidity levels in the surrounding air may cause panels to change their shape as the porous fibres shrink. This can be exaggerated during prolonged periods of dry weather. Movement and gaps in timber products are normal, in most cases the wood will revert to its original form once the high temperatures subside and there is more moisture content in the air. Similarly, in the winter months, the opposite may occur with wood swelling.



EXPANSION, CONTRACTION, SPLITS & CRACKS

All timber will expand and contract according to its environment. As a result of this expansion and contraction, it is very common to see splits and cracks developing in the wood. Splits are common during the spring and summer months as the wood begins to dry out. The outer surface dries first and contracts, contracting over a still expanded core of the wood. The result of this is that splits and cracks appear along the grain of wood. These splits are not a fault and do not affect the structural integrity of a product.



MOULD & BLUE STAIN

Mould is a surface-dwelling fungus that feeds on the nutrients and debris contained in the surface cells of timber. The most common problems associated with mould are discoloured timber and an increase in permeability of the timber. Blue stain is part of the same family but penetrates deeper into the surface layers of the timber. It stains the timber a dark blue, whereas mould is usually black. These do not cause the timber to rot. Keep the building well ventilated to avoid mould.

Treat your building annually, we advise the application of a high quality preservative that contains a mildewcide. For more information on the conditions of our guarantee see **forestgarden.co.uk**.

ADVICE ON FELT HANDLING & USAGE

Roofing felt is flexible at temperatures above 5°C. In cold temperatures extra care must be taken when handling and installing to prevent cracking and damage to the felt. The felt should not be rolled, folded or used in temperatures lower than 5°C. In cold temperatures the felt should be stored above 10°C (indoors) for 24 hours prior to use. Felt must be lifted, not dragged and should be stored on its end on a dry surface.

THE ROOF OF THIS BUILDING IS NOT A LOAD BEARING STRUCTURE

8 TOP TIPS TO ENSURE YOUR SHED IS FULLY WATERPROOF

- MAKE SURE YOU POSITION YOUR SHED IN THE BEST LOCATION IN YOUR GARDEN
 Avoid areas where water pools and is constantly wet. Position away from trees and cut back any overhanging foliage which can cause moisture to be trapped against shed walls and debris to collect on the roof.
- RAISE YOUR SHED OFF THE GROUND
 Ideally any concrete base should be the same footprint as the shed to allow surface water to run off without pooling, a timber shed base can also be used. Raise 50mm above ground level.
- SEAL THE BASE

 We recommend a treatment containing wax or oil, paint the bearers that come into contact with the ground to prevent moisture coming
- **USE AN END-GRAIN PROTECTOR**To protect the corners and panel joins, an end grain treatment can be applied.
- SEAL THE PANELS & WINDOWS

 Use a flexible silicone sealant around windows to prevent water ingress. This can also be used where 2 sections of the shed joint together. Apply internally.
- 6 CONSIDER ADDING GUTTERS

 Adding guttering around the fascia of the shed will redirect rain water away from the shed's foundation.
- KEEP VENTILATED
 Good airflow around the perimeter of the shed and regular ventilation inside the shed will help prevent mould and mildew.
- 8 CONSIDER A WEATHERPROOFING STAIN OR CLEAR TREATMENT
 We recommend you paint your garden shed with a weatherproofing treatment at least once a year. This will help maintain the wood, stabilise timber movement and help prolong the life of your shed.



TREATED TIMBER CONTAINING A BIOCIDAL PRODUCT

CONTROL OF WOOD DESTROYING ORGANISMS

Active Ingredients - Propiconazole, Tebuconazole, IPBC, Permethrine, Benzyl-C12-16-Alkyldimethyl Chlorides. (Dip Treated Sheds) Basic Copper Carbonate, DDA Carbonate, DDA Chloride. (Pressure Treated Sheds)


Wear gloves when handling. Avoid inhalation of sawdust. Do not use in contact with drinking water or food. Do not use for animal bedding or in fish ponds. Dispose of treated wood responsibly.

IDENTIFY YOUR SHED

From the section layout below, identify your shed based on the width and depth dimensions of your shed - eg 6x4. You'll need this to identify the side panel positions.

Assembly of your chosen shed will slightly differ throughout the steps based on the size of your shed. This will be mentioned throughout the instructions for guidance.

KEY




- 2ft Panel (590 x 1603mm)
 - 3ft Panel (885 x 1945mm) (With windows)
- -2ft Panel (590 x 1945mm)
- -4ft Panel (1180 x 1603mm)
- 3ft Panel (885 x 1603mm)
- 4ft Panel (1180 x 1717mm)
- -3ft Panel (885 x 1717mm)
- 4ft Panel (1180 x 1945mm) (With windows)


PLEASE NOTE


The sheds are made up of multiple sections where same size panels are interchangeable


The door is flexible for all shed types and can be hinged onto either side.















1 CONSTRUCTION 1a FLOORS & SIDES

PRE-DRILL WITH 2MM BIT FOR ALL STEPS BELOW.

Position the floor in your desired location. The 6x4 shed will only have one floor. For the 7x5, 8x6 and 10x6 sheds, turn the floors upside down to secure the sections together by screwing through the adjoining bearers. 7x5, 8x6 and 10x6 will have two floors.

Layout the panels around your shed base.


We recommend to start in a back corner then work from the back panels to the front panels for assembly.




1 Start at a back corner. See the section layout on page 4 to confirm position. Secure the corner as shown below.

Repeat the process for remaining panels and secure panels together. Make sure that the bottom frame of the wall panel rests on the outer edge of the floor.


Secure the panels into place by screwing into the floor. Screw into the door frame in the door panel into the floor to keep secure.




Attach the Triangular Pent Section by screwing to the wall panel. Also screw from the front panel into the Triangular Pent Section to keep it more secure as shown below. Repeat for the other Triangular Pent Section.




WINDOWS



Secure windows by screwing through the window cover strips and window into the panel frame. Screw into the bottom of the window and into the interior sill to keep secure. Make sure the window is centralised for all window frames as shown below.





COVER AND DOOR STRIPS





Attach the cover strips onto the corners. Ensuring they are flush to the bottom edge of the panels as shown below.


Attach the cover strips onto the adjoining panels. Ensuring it is flush to the bottom edge of the panels as shown below.

Secure the door weather strip onto the side you want the hinges, and ensure it's flush to the floor and against the face of the wall panel framing.

Attach the slamming strip onto the opposite side you want the hinges, onto the wall panel shown below.







NOTE Screwing the door weather strip onto the wall panel determines the side of your hinges.


ROOF

PRE-DRILL WITH 2MM BIT FOR ALL STEPS BELOW.

Attach the Z-brackets with screws onto the top face at each end of the beam(s).

For the 6x4 and 7x5 sheds, you will have only one beam. Screw the Z-brackets to the centre of the front and back panels (measurements shown below). Ensure the Z-brackets are facing the right way as shown below.

For the 8x6 and 10x6 sheds, you will have two beams. Use the measurements below to space them across the front and back panels and screw as shown below. Ensure the Z-brackets are facing the right way




6X4 & 7X5 SHEDS


4b

Place the OSB roof sheets, one at a time onto the shed frame and beams. Ensure where the OSB roof sheets join, are central for each beams.

Before screwing the OSB roof sheets onto the roof, screw the roof support strips to the OSB roof sheets. Ensure they are flush to the edges. Repeat this for both sides. The measurements shown below are to show the orientation of the sheets. The strip(s) will be the same length as the 2 edges when joined together as shown below.

Once the roof support strips are screwed onto the front and back of the OSB roof sheets, push the sheets forward from the back, ensuring the roof support strip is in contact with the shed as shown below. Then screw the OSB roof sheets into the beam(s) and shed frame.





30_{MM}
SCREWS

30_{MM}
SCREWS

TOP TIP: Mark onto the OSB sheet and draw a line to ensure you drill and screw into the beam(s).


Secure the fascias with screws as shown below


For the 6x4 and 7x5 sheds, screw the shorter roof support strips central onto the sheets. For the 8x6 and 10x6 sheds, screw the shorter roof support strips into the space provided as shown below.


Repeat this for both sides and ensure they are flush to the sheet edges.

Measure out equal lengths based on your chosen shed and overlap it on the top, around the edges and fold the corners; tack to keep secure as shown below. Ensure 50mm at the bottom and work from the bottom to the top.

Secure the fascias with screws as shown below
The fascia options differ based on your chosen
shed. The parts that are left over are an indiciation
on which steps to follow. Use pages 8-9 for
measurement guidance.









5 DOOR FIXINGS



Attach 2 hinges onto the door frame with the measurements provided. Please take note of the hinge position shown below. Place the door into the opening, ensuring it's level. Make sure the hinges are up against the door weather strip face. Fix the Hasp and Staple as shown. Ensure the screws go into the framework behind.





FORGET TO

PRE-DRILL AND ATTACH

YOUR FOREST BADGE

DIP TREATED & SHIPLAP PENT SHEDS

SELECT YOUR CHOSEN SHED & CHECK YOU HAVE ALL YOUR PARTS.

Overlap Pent 10' x 6' - 2 Windows (ODP106M)

Part Code **ODPMRHA6** ODP MLHA6 ODP/M885BP

Section D - 3ft Pent Back Panel Section G - 4ft Pent Back Panel

(885 x 1717mm) Left Hand

Right Hand 6ft Triangular Pent Section -Description
6ft Triangular Pent Section

ē Č	Overlap Pent 6' x 4' - 2 Windows (ODP64M)			Overlap Pent / >
Part Code	Description	No.	Part Code	
	4ft Triangular Pent Section -			5ft T
ODP MRHA4	Right Hand	_	ODP/MRHA5	
	4ft Triangular Pent Section -			5ft T
ODPMLHA4	Left Hand	1	ODPMLHA5	
	Section D - 3ft Pent Back Panel			Section
ODPM885BP	(885 x 1717mm)	7	ODP/M885BP	
	Section E - 3ft Pent Front Window Panel			Section
ODM885TWP	(885 x 1945mm)	-	ODPM1180BP	
	3ft Pent Front Door Panel			3ft
ODM885TDP	(885 x 1945mm)	_	ODM885TDP	
	Section F - 4ft Panel			
ODM1180PP	(1180 x 1603mm)	7	ODM885PP	
	ı			
MSDDR	Door	-	ODM590PP	
				Section H
MSBFL46	Floor	7	ODM1180TWP	
28121637PDT	Slamming Strip (28x12x1637mm)	-	MSDDR	
28160550DT	Window Cover Strip (28x16x550mm)	က	MSBFL 257	
28280973	Roof Support Strip (28x28x973mm)	2	28121637PDT	Slamm
28281934	Roof Support Strip (28x28x1934mm)	2	28160550DT	Window
38121710PDT	Weather Strip (38x12x1710mm)	-	28281115	Roof Sul
44161695DT	Cover Strip (44x16x1695mm)	3	38121710PDT	Weath
44161925DT	Cover Strip (44x16x1925mm)	3	44161695DT	Cove
45451153PAII79	Roof Beam (45x45x1153mm)	-	44161810DT	Cove
59121390PDT	Fascia (59x12x1390mm)	2	44161925DT	Cove
59121978PDT	Fascia (59x12x1978mm)	-	45451441PAII81	Roof
RPET885	Window	2	59121132PDT	Fa
OSB13759678	OSB Sheet - Roof	2	59121688PDT	Fa
	Felt	1	RPET590	
			01777000700	

Part Code	## Triangular Pent Section - ## Triangular Pent Section - ## Triangular Pent Section - ## Section D - 34 Pent Back Panel ## Section G - 44 Pent Back Panel ## (1480 x 1717mm) ## (885 x 1477mm) ## (885 x 1494mm) ## Section A - 24 Panel ## (1480 x 1603mm) ## Section H - 44 Pent Front Window Panel ## (1480 x 1694mm) ## Door ## Poor Telor ## Pent Front Window Panel ## (1480 x 1945mm) ## Poor Telor ## Pent Front Window Panel ## Pent F	<u>0</u>	Part Code ODP MRHA6 ODPM1180BP ODM1180TUP ODM1180TUP MSDDR MSBFL46 28121637PDT 28160550DT 28281242 28281242 283281241 A14460DT A14460	Control of the Cont
38121710PDT 44161695DT 44161810DT	Weather Strip (38x12x1/10mm) Cover Strip (44x16x1695mm) Cover Strip (44x16x1810mm)	- 6 2	44161695DT 44161810DT 44161925DT	Cover Strip (44x16x1695mm) Cover Strip (44x16x1810mm) Cover Strip (44x16x1925mm)
44161925DT 45451441PAII81	Cover Strip (44x16x1925mm) Roof Beam (45x45x1441mm)	د -	45451783PAII83 59121020PDT	Roof Beam (45x45x1783mm) Fascia (59x12x1020mm)
59121132PDT 59121688PDT	Fascia (59x12x1132mm) Fascia (59x12x1688mm)	2 2	59121259PDT RPET590	Fascia (59x12x1259mm) Window
RPET590 OSB168811158	Window OSB Sheet - Roof	7	OSB20328288	OSB Sheet - Roof Felt
	Felt	-		

Section H - 4ft Pent Front Window Panel

4ft Pent Front Door Pane

(1180 x 1945mm)

(1180 x 1945mm)

ODM1180TWP ODM1180TDP

ODM590TPP

ODM885PP

Section B - 2ft Pent Front Panel

Section C - 3ft Pane

(885 x 1603mm) (590 x 1945mm)

(1180 x 1717mm)

Roof Support Strip (28x28x1537mm) Weather Strip (38x12x1710mm)

Cover Strip (44x16x1895mm)
Cover Strip (44x16x1810mm)
Cover Strip (44x16x1925mm)
Roof Beam (45x45x1783mm)
Fascia (59x12x1020mm)
Fascia (59x12x1655mm)
Window

45451783PAII83

44161695DT

44161810DT 44161925DT OSB Sheet - Roof

Felt

SDPMRHA5 SDPMLHA5

4ft Triangular Pent Section - Right Hand 1

SDPMLHA4

Shiplap Pent 6' x 4' - 2 Windows (SDP64M)

SDPM885BP

(885 x 1717mm) Section E - 3ft Pent Front Window Panel

(885 x 1945mm) 3ft Pent Front Door Panel

(885 x 1945mm)

Section D - 3ft Pent Back Panel

SDM885TDP

SDM885PP SDM590PP

Section F - 4ft Panel (1180 x 1603mm)

SDM1180PP

MSDDR

Slamming Strip (28x12x1637mm) Window Cover Strip (28x16x550mm) Roof Support Strip (28x28x988mm)

28160550DT

28280988 28281537

-			CANODE CONTRACTOR TO THE PARTY OF THE PARTY
	No.	Part Code	Description
Hand	-	SDPMRHA6	6ft Triangular Pent Section - Right Hand
and	-	SDPMLHA6	6ft Triangular Pent Section - Left Hand
			Section G - 4ft Pent Back Panel
	1	SDPM1180BP	(1180 x 1717mm)
	1	SDM885PP	Section C - 3ft Panel (885 x 1603mm)
			Section H - 4ft Pent Front Window Panel
	1	SDM1180TWP	(1180 x 1945mm)
			4ft Pent Front Door Panel
(mı	2	SDM1180TDP	(1180 x 1945mm)
Œ	7	MSDDR	Door
anel			i
	-	MSBFL46	Floor
	1	28121637PDT	Slamming Strip (28x12x1637mm)
	7	28120550PDT	Window Cover Strip (28x12x550mm)
(mi	က	28280988	Roof Support Strip (28x28x988mm)
<u> </u>	-	28281242	Roof Support Strip (28x28x1242mm)
(mi	9	38121710PDT	Weather Strip (38x12x1710mm)
	1	40121695PDT	Cover Strip (40x12x1695mm)
	က	40121810PDT	Cover Strip (40x12x1810mm)
	2	40121925PDT	Cover Strip (40x12x1925mm)
	က	45451783PAII83	Roof Beam (45x45x1783mm)
	-	59121020PDT	Fascia (59x12x1020mm)
	7	59121259PDT	Fascia (59x12x1259mm)
	2	RPET590	Window
	2	OSB20328288	OSB Sheet - Roof
	7		Felt

Pent 7' x 5' - 2 Windows (SDP75M)		Ship	Shiplap Pent 8' x 6' - 2 Windov
Description	No.	Part Code	Descripti
ft Triangular Pent Section - Right Hand	1	SDPMRHA6	6ft Triangular Pent Seci
5ft Triangular Pent Section - Left Hand	1	SDPMLHA6	6ft Triangular Pent Sec
Section D - 3ft Pent Back Panel			Section G - 4ft Pen
(885 x 1717mm)	_	SDPM1180BP	(1180 × 171)
Section G - 3ft Pent Back Panel			
(1180 x 1717mm)	_	SDM885PP	Section C - 3ft Panel (
3ft Pent Front Door Panel			Section H - 4ft Pent Fro
(885 x 1945mm)	_	SDM1180TWP	(1180 x 194
			4ft Pent Front D
Section C - 3ft Panel (885 x 1603mm)	7	SDM1180TDP	(1180 x 194
Section A - 2ft Panel (590 x 1603mm)	7	MSDDR	Door
ection H - 4ft Pent Front Window Panel			
(1180 x 1945mm)	_	MSBFL46	Floor
Door	1	28121637PDT	Slamming Strip (28)
Floor	2	28120550PDT	Window Cover Strip (
Window Cover Strip (28x12x550mm)	က	28280988	Roof Support Strip (2
Slamming Strip (28x12x1637mm)	1	28281242	Roof Support Strip (2
Roof Support Strip (28x28x1115mm)	9	38121710PDT	Weather Strip (38x
Weather Strip (38x12x1710mm)	1	40121695PDT	Cover Strip (40x1)
Cover Strip (40x12x1695mm)	3	40121810PDT	Cover Strip (40x1)
Cover Strip (40x12x1810mm)	2	40121925PDT	Cover Strip (40x1)
Cover Strip (40x12x1925mm)	3	45451783PAII83	Roof Beam (45x4
Roof Beam (45x45x1441mm)	1	59121020PDT	Fascia (59x12x
Fascia (59x12x1132mm)	2	59121259PDT	Fascia (59x12x
Fascia (59x12x1688mm)	7	RPET590	Windov
Window	2	OSB20328288	OSB Sheet
OSB Sheet - Roof	2		Felt
Felt	1		

40121925PDT 45451441PAII81

59121132PDT

OSB Sheet - Roof

40121810PDT

40121695PDT

Weather Strip (38x12x1710mm)
Cover Strip (40x12x1695mm)
Cover Strip (40x12x1925mm)
Roof Beam (45x45x1153mm)
Fascia (59x12x1390mm)
Fascia (59x12x1390mm)

45451153PAII79 40121695PDT 40121925PDT

RPET885

OSB168811158

RPET590

28121637PDT 38121710PDT

Roof Support Strip (28x28x973mm) Roof Support Strip (28x28x1934mm) Window Cover Strip (28x12x550mm) Slamming Strip (28x12x1637mm)

28120550PDT 28121637PDT

28280973 28281934

MSBFL46

28281115

28120550PDT

MSBFL 257

SDM1180TWP

(The parts do not have codes on them. They are listed above should you need to order one.) Please contact our aftersales team with your product code if you are missing your felt.

PRESSURE TREATED PENT SHEDS

SELECT YOUR CHOSEN SHED & CHECK YOU HAVE ALL YOUR PARTS.

Ove	Overlap Pent 6' x 4' - 2 Windows (OPP64M)		Over	Overlap Pent 7' x 5' - 2 Windows (OPP75M)		Over	Overlap Pent 8' x 6' - 2 Windows (OPP86M)		Overlap	Overlap Pent 10' x 6' - 2
Part Code		No.	Part Code	Description	No.	Part Code	Description	No.	Part Code	٥
OPPMRHA4	4ft Triangular Pent Section - Right Hand	-	OPP/MRHA5	5ft Triangular Pent Section - Right Hand	-	OPPMRHA6	6ft Triangular Pent Section - Right Hand	-	OPPMRHA6	6ft Triangular P
OPPMLHA4	4ft Triangular Pent Section - Left Hand	-	ОРРМІНАБ	5ft Triangular Pent Section - Left Hand	-	ОРРМІНАВ	6ft Triangular Pent Section - Left Hand	-	ОРРМІНАВ	6ft Triangular F
	Section D - 3ft Pent Back Panel			Section D - 3ft Pent Back Panel			Section G - 4ft Pent Back Panel			Section D -
OPPM885BP	(885 x 1717mm)	7	OPPM885BP	(885 x 1717mm)	-	OPPM1180BP	(1180 x 1717mm)	7	OPPM885BP	(88
	Section E - 3ft Pent Front Window Panel			Section G - 3ft Pent Back Panel						Section G -
OPM885TWP	(885 x 1945mm)	-	OPPM1180BP	(1180 x 1717mm)	-	OPM885PP	Section C - 3ft Panel (885 x 1603mm)	4	OPPM1180BP	(118
	3ft Pent Front Door Panel			3ft Pent Front Door Panel			Section H - 4ft Pent Front Window Panel			
OPM885TDP	(885 x 1945mm)	-	OPM885TDP	(885 x 1945mm)	-	OPM1180TWP	(1180 x 1945mm)	-	OPM885PP	Section C - 3ft
							4ft Pent Front Door Panel			Section B -
OPM1180PP	Section F - 4ft Panel (1180 x 1603mm)	7	OPM885PP	Section C - 3ft Panel (885 x 1603mm)	7	OPM1180TDP	(1180 x 1945mm)	-	OPM590TPP	(29
										Section H - 4ft P
MSPDR	Door	-	OPM590PP	Section A - 2ft Panel (590 x 1603mm)	2	MSPDR	Door	-	OPM1180TWP	(118
				Section H - 4ft Pent Front Window Panel						4ft Pent
MSBFL46	Floor	-	OPM1180TWP	(1180 x 1945mm)	-	MSBFL46	Floor	7	OPM1180TDP	(118
28121637PPT	Slamming Strip (28x12x1637mm)	-	MSPDR	Door	-	28121637PPT	Slamming Strip (28x12x1637mm)	-	MSPDR	
28160550PT	Window Cover Strip (28x16x550mm)	3	MSBFL 257	Floor	2	28160550PT	Window Cover Strip (28x16x550mm)	3	MSBFL56	
28280973	Roof Support Strip (28x28x973mm)	2	28121637PPT	Slamming Strip (28x12x1637mm)	1	28280988	Roof Support Strip (28x28x988mm)	4	28121637PPT	Slamming S
28281934	Roof Support Strip (28x28x1934mm)	7	28160550PT	Window Cover Strip (28x16x550mm)	3	28281242	Roof Support Strip (28x28x1242mm)	4	28160550PT	Window Cove
38121710PPT	Weather Strip (38x12x1710mm)	-	28281115	Roof Support Strip (28x28x1115mm)	9	38121710PPT	Weather Strip (38x12x1710mm)	1	28280988	Roof Support
44161695PT	Cover Strip (44x16x1695mm)	3	38121710PPT	Weather Strip (38x12x1710mm)	1	44161695PT	Cover Strip (44x16x1695mm)	3	28281537	Roof Support
44161925PT	Cover Strip (44x16x1925mm)	3	44161695PT	Cover Strip (44x16x1695mm)	3	44161810PT	Cover Strip (44x16x1810mm)	2	38121710PPT	Weather St
45451153PAII79	Roof Beam (45x45x1153mm)	-	44161810PT	Cover Strip (44x16x1810mm)	7	44161925PT	Cover Strip (44x16x1925mm)	က	44161695PT	Cover Stri
59121390PPT	Fascia (59x12x1390mm)	2	44161925PT	Cover Strip (44x16x1925mm)	3	45451783PAII83	Roof Beam (45x45x1783mm)	2	44161810PT	Cover Stri
59121978PPT	Fascia (59x12x1978mm)	-	45451441PAII81	Roof Beam (45x45x1441mm)	7	59121020PPT	Fascia (59x12x1020mm)	4	44161925PT	Cover Stri
RPET885	Window	7	59121132PPT	Fascia (59x12x1132mm)	2	59121259PPT	Fascia (59x12x1259mm)	7	45451783PAII83	Roof Bear
OSB13759678	OSB Sheet - Roof	2	59121688PPT	Fascia (59x12x1688mm)	2	RPET590	Window	2	59121020PPT	Fascia
	Felt	-	RPET590	Window	7	OSB20328288	OSB Sheet - Roof	က	59121555PPT	Fascia
			011110001000	OCD Choof Doof	c		7142	,	000000000000000000000000000000000000000	

1000	٠ No	Part Code	Description	No.
пнапа	-	OPP/MRHA6	6ft Triangular Pent Section - Right Hand	1
t Hand	_	ОРРМІНАВ	6ft Triangular Pent Section - Left Hand	-
nel			Section D - 3ft Pent Back Panel	
	2	OPPM885BP	(885 x 1717mm)	2
			Section G - 4ft Pent Back Panel	
3mm)	4	OPPM1180BP	(1180 x 1717mm)	1
v Panel	7	CCCCONTCC	Section C - 2# Danel (895 × 4603mm)	_
	-	Crimosorr	Section C - Sit Failer (605 x 100511111)	٠
			Section B - 2tt Pent Front Panel	
	-	OPM590TPP	(590 x 1945mm)	1
			Section H - 4ft Pent Front Window Panel	
	_	OPM1180TWP	(1180 x 1945mm)	_
			4ft Pent Front Door Panel	
	7	OPM1180TDP	(1180 x 1945mm)	-
uu)	-	MSPDR	Door	1
0mm)	က	MSBFL56	Floor	7
lmm)	4	28121637PPT	Slamming Strip (28x12x1637mm)	1
2mm)	4	28160550PT	Window Cover Strip (28x16x550mm)	ო
m)	-	28280988	Roof Support Strip (28x28x988mm)	4
<u>-</u>	က	28281537	Roof Support Strip (28x28x1537mm)	4
(7	38121710PPT	Weather Strip (38x12x1710mm)	1
(·	က	44161695PT	Cover Strip (44x16x1695mm)	4
(r	7	44161810PT	Cover Strip (44x16x1810mm)	7
	4	44161925PT	Cover Strip (44x16x1925mm)	4
	7	45451783PAII83	Roof Beam (45x45x1783mm)	7
	7	59121020PPT	Fascia (59x12x1020mm)	4
	က	59121555PPT	Fascia (59x12x1555mm)	7
	-	RPET590	Window	7
		OSB203210258	OSB Sheet - Roof	3
			Felt	1

(The parts do not have codes on them. They are listed above should you need to order one.) Please contact our aftersales team with your product code if you are missing your felt.